

# Air Check Sample Draw Oxygen Monitor



Air Check O<sub>2</sub> Deficiency Monitor  
Digital O<sub>2</sub> concentration display  
Two User selectable Alarm relays  
24VDC powered 500mA  
NEMA 4X enclosure  
4-20mA datalog output  
No drift oxygen sensor, average life 10+ years  
User selectable hysteresis for process control  
Wall mounted

Dual User Selectable Audio/Visual  
Alarm 2amp 30VDC / 240VAC



LP7-18-30R

Supervised 4-20mA output to  
PLC 4mA = 0ppm  
20mA = Full scale  
2mA = System Fault  
0mA = Loss of Power



Remote  
Display

General Cable  
#E2203 \$30.86  
3 conductor 18 awg  
stranded shielded  
Max distance 3,000 ft.

**Regulated PSU** pH T1000-P5P-ND  
110VAC  
24VDC 1.0 amp  
Wall plugin type

**PureAire**  
monitoring systems, inc.